

Wi-Safe Vibrating and Strobe Alert

Important note when testing

Once your Wi-Safe system is up and running you will need to test it. To test the system you need to press the test button on your smoke/CO alarm, this will cause your Vibrating Pad to vibrate and the strobe will also flash where fitted (WFSVP-629/WFS-627 products only)

When testing your Wi-safe system the length of time that the Vibrating Pad vibrates and the Strobe flashes varies and can vary significantly from test to test even with the same alarm. Also the length of time of operation will in most cases differ from the length of the alarm sound given off by the smoke or CO alarm. This is normal.

Please note that in a real alarm situation the vibrating pad will vibrate (and the strobe will flash where fitted) continuously while the smoke/CO unit is in alarm. Should you have any queries regarding this please contact the Technical Support Team on 024 7623 6663 or by email at technicalsupport@fireangel.co.uk