



WIRELESS INTERLINK GATEWAY

Installation Guide

WG-2

Drill hole spacing



FireAngel Safety Technology Limited
Vanguard Centre, Coventry CV4 7EZ UK



Model No. WG-2



GN5520R1

INSTALLATION INSTRUCTIONS

1. The Gateway is designed to lie flat or be secured to a wall.
2. If required, use the supplied plastic anchors and screws to fit the Gateway to the wall.

Mounting on a wall:

Please ensure that you use the screws provided, as they were chosen specifically for use with this product.



Use the template provided (opposite) for guidance on marking hole positions. Drill holes into the wall. Insert the plastic wall plugs. Screw in the screws. Ensure screws are protruding from the wall by 3mm to allow the Gateway to slot onto screws.

3. Connect Power cable here 

4. Connect Ethernet cable here 

Make a note of the MAC address prior to permanent installation as you will need this when activating the Gateway for the first time.

To remove the Gateway from a wall: Insert a small screwdriver into the hole on the side and use it to slide the Gateway up. The Gateway will lift off the screws that attach it to the wall.

SETTING UP YOUR GATEWAY

Follow the set-up instructions at:

www.fireangelconnect.com



The WG-2 Gateway allows for Wi-Safe 2 devices to connect to the internet. The FireAngelConnect app works in conjunction with the Gateway to enable real time alerts, networking and testing of your safety alarm system.

Please note: an internet connection is required when setting up an alarm network for the first time, in conjunction with the Gateway.

LIMITATIONS

The Wi-Safe 2 protocol is not a life safety protocol and should not be relied upon for life safety. If your internet connection is lost, communication from the WG-2 (i.e. to cloud or mobile devices) may not be possible. The local Wi-Safe 2 alarm network will still continue to operate as a stand-alone system and does not rely on an internet connection to do so.

WARRANTY

For information on individual alarm warranty please refer to the main alarm manual.

FireAngel Safety Technology Limited warrants to the original purchaser that its enclosed WG-2 to be free from defects in materials and workmanship under normal residential use and service for a period of 2 (two) years from the date of purchase. Provided it is returned with proof of purchase date, FireAngel Safety Technology Limited hereby warrants that during the 2 (two) year period commencing from the date of purchase FireAngel Safety Technology Limited, at its discretion, agrees to replace the unit free of charge.

The warranty on any replacement WG-2, will last for the remainder of the period of the original warranty in respect of the wireless module originally purchased – that is from the date of original purchase and not from the date of receipt of the replacement product.

FireAngel Safety Technology Limited reserves the right to offer an alternative product similar to that being replaced if the original model is no longer available or in stock. This warranty applies to the original retail purchaser from the date of original retail purchase and is not transferable. Proof of purchase is required. This warranty does not cover damage resulting from accident, misuse, disassembly, abuse or lack of reasonable care of the product, or applications not in accordance with the user manual. It does not cover events and conditions outside of FireAngel Safety Technology Limited's control, such as Acts of God (fire, severe weather etc.). It does not apply to retail stores, service centres or any distributors or agents. FireAngel Safety Technology Limited will not recognise any changes to this warranty by third parties.

FireAngel Safety Technology Limited shall not be liable for any incidental or

consequential damages caused by the breach of any expressed or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration for 2 (two) years. This warranty does not affect your statutory rights. Except for death or personal injury, FireAngel Safety Technology Limited shall not be liable for any loss of use, damage, cost or expense relating to this product or for any indirect or consequential loss, damages or costs incurred by you or any other user of this product.

DISPOSAL

Waste electrical products should not be disposed of with your other household waste, but within the waste electronic and electrical equipment (WEEE) recycling scheme.

WARNING: Do not attempt to disassemble. Do not burn or dispose of in fire.

TECHNICAL SPECIFICATION

The WG-2 Gateway is designed to be installed in conjunction with Wi-Safe 2 (protocol) compatible devices. For more information visit:

www.fireangelconnect.com

230V Mains Powered, 5V DC, 1A

Independently tested to RF standard:

EN 300 220-2

EN 301 489-3

EN 301 489-1

Max RF power: +10dBm

Frequency 868MHz

Hereby, FireAngel Safety Technology Limited declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at <http://spru.es/WG-2>

Manufacturer: FireAngel Safety Technology Limited, Vanguard Centre, Sir William Lyons Rd, Coventry, CV4 7EZ, UK

For more information visit:
www.fireangelconnect.com

(UK) technicalsupport@fireangeltech.com

(DE) technik@fireangeltech.com

(FR) supporttechnique@fireangeltech.com

(NL) klantenservice@fireangeltech.com

(INT) Internationalsupport@fireangeltech.com