

CO-808 Manual / CO-808S Manual Addendum

When used with the BP-808 Backing Plate, your CO-808 or CO-808S is ideal for mounting on the ceiling.

To do this, attach the BP-808 Backing Plate to the ceiling and simply clip the alarm in place.

Install the alarm at a horizontal distance of 1-3 metres from any appliance. The alarm should also be a minimum of 150mm (6") from any wall.

Make sure that the alarm is held securely by the backing plate.

If there is a partition in the room, the apparatus should be located on the same side of the partition as the potential source.

